



Instructions for photo collage with gallery frame




1 Unpack and assemble carefully to avoid surface scratches. Use both hands to hold the product on each side. Check that all swivel clamps are properly attached. These can come loose during transport or when holding with just one hand on one side. The swivel clamps can be screwed back in.



2 Hang the product on the designated mount. The mounting device is pre-assembled. Please do not attach a piece of string or wire to the wall mountings and hang this over a single hook in the middle!

3 Please use hooks and dowels to suit the condition of the wall. These are sold separately and are not supplied as part of the delivery.



Weight per product:
 40×110 cm approx. 2.5 kg
 50×70 cm approx. 2 kg

General instructions

We have put together a few tips for you to ensure that you can enjoy this product for a long time to come:

The swivel clamps can come loose during transport, simply screw them back in.

Grab and hold the frame on each side using both hands.

Hang up on the designated mount.

To clean, use a feather duster or a soft and dry cloth only. Do not use cleaning agents under any circumstances.

Avoid intense heat and direct sunlight.

Do not hang directly over a radiator.

Not suitable for outdoor use.